

HOW TO ENJOY THE MAX COMFORT WITH AZERON



BEFORE





AFTER

NB! Classic and Compact keypads both have been **DESIGNED TO PERFECTLY FIT TO YOUR HAND**. Keep in mind - keypad should **FOLLOW THE SHAPE OF YOUR HAND** and not vice versa to adjust perfectly and enjoy the **UNRIVALLED ERGONOMICS**. Naturally contoured design follows the natural shape of your hand **FOR INCREASED COMFORT DURING LONG GAMING SESSIONS**. Adjust it accurately to have fun with the full potential, do not use it straight out the box!

1 ANALOG 360 MOVEMENT

After unboxing, rotate the thumbtower until you can reach the thumbnail button and thumbstick easily. Use included hex key to fix the screw. **THUMBSTICK REPLACES WASD**, so, it is urgent to double check if it feels natural to move with it. Also, can you reach the 5-way directional key easily? P.S. Change the thumbstick cap by slightly pulling it off to find the best fit (3 different caps included).



Change the angles between **OMRON SWITCH KEY** towers - slightly loosen the screws of key towers until each tower fits your fingers naturally. Remember - adjust the keypad to your hand and not vice versa! **TOWERS COMPLEMENT YOUR NATURAL CLAW GRIP OF YOUR FINGERS**. Even if you have loooong fingers you will find your best fit.

2 ADJUSTABLE KEY TOWERS



3 BUTTONS AT YOUR FINGERTIPS

Adjust the tower distance from the palmrest to the key towers. Slightly loosen the screws on the rails just enough to slide the towers **TO FIND YOUR OWN PERFECT FIT**. Slide each tower when you are able reach all the buttons easily. Fix them with the hex key. Check that you feel comfortable and you don't have to lift up/down or move your palm. Pressing the buttons should feel easy with less effort possible - **ALL THE CONTROLS AT YOUR FINGERTIPS**.

